


Instruments and Controls

For more detailed descriptions see quoted pages.

- 
- 1** Speaker grilles
 - 2** Swivelling side ventilation outlets (page 28)
 - 3** Parking brake release knob (page 48)
 - 4** Hood lock release handle (page 46)
 - 5** Parking brake pedal (page 48)
 - 6** Combination switch (page 26)
 - 7** Lighting switch (page 25)
 - 8** Cruise control (page 27)
 - 9** Instrument cluster (page 10)
 - 10** Horn control
 - 11** Steering lock with preglow/starter switch (page 24)
 - 12** Swivelling outlets for cooled air (page 28)
 - 13** Switch for rear courtesy lamp (page 35)
 - 14** Switch for automatic antenna (page 43)
 - 15** Switch for electric sliding roof (page 37)
 - 16** Switch for heated rear window (page 34)
 - 17** Automatic climate control (page 28)
 - 18** Radio (page 38)
 - 19** Ash tray with lighter (pages 37, 64)
 - 20** Switch for left front seat heater (page 16)
 - 21** Switch for hazard warning flasher system
 - 22** Switch for right front seat heater (page 16)
 - 23** Switch group for power windows (page 36)
 - 24** Adjusting lever for exterior mirror on front passenger side (page 33)
 - 25** Loudspeaker — fader control
 - 26** Glove compartment, illuminated (only if steering lock is in position "1" or "2")
To open, move handle sideways

Instruments and Controls

